

EQUITONE [natura], [natura pro], & [pictura] Cleaning Instructions

Options 1, 2, & 3 are for small scale cleaning. Options 4 & 5 are for large scale cleaning.

Option 1

- Wet sponge or cloth.
- Running water from a hosepipe.

Option 2

- Rubber eraser
- Wipe away the dust with dry microfibre cloth.
- Wet sponge or cloth.
- Running water from a hosepipe.

Option 3

- Cleaning agent solution consists of commercially available, ammonia-free dish washing-liquid or ammonia-free multipurpose cleaner.
- Wet sponge or cloth.
- Running water from a hosepipe.

Option 4

- High pressure cleaner with clean water at a maximum pressure of 125 bar and a maximum flow rate of 10 litres/minute.
- One must spray perpendicular to the surface at a distance of at least 25 cm.

Option 5

- Cleaning agent solution consists of commercially available, ammonia-free dish washing-liquid or ammonia-free multipurpose cleaner.
- High pressure cleaner with clean water at a maximum pressure of 125 bar and a maximum flow rate of 10 litres/minute.
- One must spray perpendicular to the surface at a distance of at least 25 cm.

Special Notes for EQUITONE [natura pro] & [pictura]

- Use ammonia-free paint remover/cleaner to remove paint related stains on the surface of the panels.

For further information, please consult with EQUITONE Asia Pacific Technical Department.

EQUITONE Asia Pacific

www.equitone.com

info.asia@equitone.com

info.australia@equitone.com